

Build-It[®] Core Forms

1. Tooth with a root canal post.
2. Select pre-formed core build-up cap.
3. Fill the pre-formed cap with light curing or self curing composite.
4. Place cap over tooth and root canal post.
5. After curing the composite, remove pre-formed cap.
6. Finish the preparation in the cervical and occlusal area.